

Programme auf Bank 60 (CC 0)

	<b>Bank 60 (normal)</b>	<b>Bank 61 (Akkorde)</b>	<b>Bank 62 (Eb)</b>	<b>Bank 63 (D)</b>
<b>AZ-10 kurz</b>	0	0		
<b>AZ-10 normal</b>	1	1		
<b>Texan kurz</b>	2	2		
<b>Texan normal</b>	3	3		
<b>Erman normal</b>	4	4		
<b>Erman lang</b>	5	5		
<b>Erman Git/Bass</b>	6			
<b>AZ-10 Git/Bass</b>	7			
<b>Texan Git/Bass</b>	8			
<b>AZ-10 Ausklingend</b>	9	9		
<b>Kontrabass ausklingend</b>	10		10	10
<b>Kontrabass weich</b>	11		11	11
<b>Kontrabass normal</b>	12		12	12
<b>Kontrabass hart</b>	13		13	13
<b>E-Bass hart</b>	14		14	14
<b>E-Bass mittel</b>	15		15	15
<b>E-Bass fett</b>	16		16	16
<b>E-Bass normal</b>	17		17	17
<b>E-Bass ausklingend</b>	18		18	18
<b>E-Bass kurz</b>	19		19	19
<b>Bariton Lechner kurz</b>	20		20	20
<b>Bariton Lechner normal</b>	21		21	21
<b>Bariton Weber kurz</b>	22		22	22
<b>Bariton Weber normal</b>	23		23	23
<b>Bariton King 1 Kurz</b>	24		24	24
<b>Bariton King 1 Normal</b>	25		25	25
<b>Bariton King 2 Kurz</b>	26		26	26
<b>Bariton King 2 Normal</b>	27		27	27
<b>Bariton Lechner fett</b>	28		28	28
<b>AZ-10 Ausklingend normal</b>	29	29		
<b>Hohner Morino Reg 5 Musette</b>	30			
<b>Zupan Alpe III</b>	31			
<b>Steirische 3-ch</b>	32			
<b>Steirische 1ch</b>	33			
<b>Steirische 2ch I</b>	34			
<b>Steirische 2ch II</b>	35			
<b>Alpengold 3-ch</b>	36			
<b>Alpengold 1-ch</b>	37			
<b>Alpengold 2-ch I</b>	38			

	Bank 60 (normal)	Bank 61 (Akkorde)	Bank 62 (Eb)	Bank 63 (D)
Alpengold 2-ch II	39			
Akkordeon Helikon	40			
Akkordeon Zupan Bass	41			
Akkordeon Zupan Akkorde	42	42		
Musette Américain	43			
Musette Parisien	44			
Musette Céleste	45			
Piermaria Gala 1	46			
Piermaria Gala 2	47			
Alpengold Steirische	48			
Zupan Steirische 3-R	49			
Starter Kontrabass kurz	50			
Starter Gitarre kurz	51	51		
Starter Bariton kurz	52		52	52
	53			
Ales Kontrabass Normal	54		54	54
Ales Kontrabass Diskant hoch	55			
Ales Kontrabass Diskant tief	56			
Ales Kontrabass Ausklingend	57		57	57
Bariton King 1 Diskant	58			
Bariton King 2 Diskant	59			
Trompete Hans	60			
Trompete Hans Loop	61			
Klarinette Turboreini	62			
Klarinette Turboreini Loop	63			
Tenorhorn Weich	64			
Tenorhorn Normal	65			
Tenorhorn Akkorde	66			
Flügelhorn 2	68			
Flügelhorn 1	69			
4 Tiroler Bass kurz	70		70	70
4 Tiroler Bass 1	71		71	71
4 Tiroler Bass 2	72		72	72
4 Tiroler Bass 3	73		73	73
4 Tiroler Diskant 1	74			
Geige Crescendo	75			
Geige Crescendo Loop	76			
Geige 1	77			
Geige 2	78			
Hohner Alpina 3	79			

	<b>Bank 60 (normal)</b>	<b>Bank 61 (Akkorde)</b>	<b>Bank 62 (Eb)</b>	<b>Bank 63 (D)</b>
<b>Ovation 4 Kurz</b>	80	80		
<b>Ovation 4 Mittel</b>	81	81		
<b>Ovation 4 Lang</b>	82	82		
<b>Ovation 4 GitBass</b>	83			
<b>Harfe Diskant</b>	84			
<b>Harfe Bass</b>	85		85	85
<b>Harfe Akkorde arpeggio</b>	86	86		
<b>Harfe Akkorde</b>	87	87		
<b>Harfe Diskant ausklingend</b>	88			
<b>Harfe Akkorde ausklingend</b>	89	89		
<b>Hackbrett Weich</b>	90			
<b>Hackbrett Weich ausklingend</b>	91			
<b>Hackbrett Hart</b>	92			
<b>Hackbrett Hart ausklingend</b>	93			
<b>Panflöte 1</b>	94			
<b>Panflöte 2</b>	95			
<b>Panflöte 3</b>	96			
<b>Klarinette Mitja</b>	97			
<b>Klarinette Mitja Loop</b>	98			
<b>Panflöte 4</b>	99			
<b>Tuba B Bass</b>	100		100	100
<b>Tuba F Bass lang</b>	101		101	101
<b>Tuba F Bass</b>	102		102	102
<b>Tuba F Diskant</b>	103			
<b>Posaune Bass Hart</b>	104		104	104
<b>Posaune Zug</b>	105			
<b>Posaune Ventil</b>	106			
<b>Posaune Bass Weich</b>	107		107	107
<b>Tuba B Tief</b>	108		108	108
<b>Tuba F Tief</b>	109		109	109
<b>Italo Bass + Git</b>	110		110	110
<b>Italo E-Bass</b>	111		111	111
<b>Italo Squier Git 1</b>	112		112	112
<b>Italo Squier Git 2</b>	113		113	113
<b>Italo Squier Git 3</b>	114		114	114
<b>Italo Squier Strat</b>	115			
<b>Ales Kontrabass Normal Ois isi</b>	116			
<b>Tuba F Ois isi</b>	117			
<b>Alphorn 4</b>	118			
<b>Alphorn 4 Loop</b>	119			

	<b>Bank 60 (normal)</b>	<b>Bank 61 (Akkorde)</b>	<b>Bank 62 (Eb)</b>	<b>Bank 63 (D)</b>
<b>Vibraphon Kurz</b>	120			
<b>Vibraphon Normal</b>	121			
<b>Trompete Jan</b>	122			
<b>Vibraphon Lang</b>	123			
<b>Vibraphon Vibrato 1</b>	124			
<b>Vibraphon Vibrato 2</b>	125			
<b>Vibraphon Vibrato 3</b>	126			

Programme auf Bank 70 (CC 0)

	<b>Bank 70 (normal)</b>	<b>Bank 71 (Akkorde)</b>	<b>Bank 72 (Eb)</b>	<b>Bank 73 (D)</b>
<b>Base Drum 1</b>	0			
<b>Becken</b>	1			
<b>Becken Glocke</b>	2			
	3			
<b>Hi-Hat geschlossen</b>	4			
<b>Hi-Hat offen</b>	5			
<b>Hi-Hat Stick</b>	6			
<b>Ride Becken</b>	7			
<b>Rimshot</b>	8			
<b>Snare 1</b>	9			
<b>Snare 2</b>	10			
<b>Base Drum 2</b>	11			
<b>Snare Wirbel 1</b>	12			
<b>Snare Wirbel 2</b>	13			
<b>Snare Wirbel 3</b>	14			
<b>Wirbel Solo</b>	15			
<b>Höfner Jazz-Gitarre</b>	16			
<b>Höfner Jazz-Gitarre Oct</b>	17			
<b>Höfner Jazz-Gitarre Chorus</b>	18			
<b>Höfner Jazz-Gitarre Oct St</b>	19			
<b>Zither Akkorde 1</b>	20			
<b>Zither Diskant 1</b>	21			
<b>Zither Diskant 1 Vibrato</b>	22			
<b>Zither Bass</b>	23			
<b>Zither Diskant 2</b>	24			
<b>Zither Diskant 2 Vibrato</b>	25			
<b>Zither Akkorde 2</b>	26			

	<b>Bank 70 (normal)</b>	<b>Bank 71 (Akkorde)</b>	<b>Bank 72 (Eb)</b>	<b>Bank 73 (D)</b>
<b>Zither Bass Ausklingend</b>	27			
<b>Zither Akkorde Ausklingend</b>	28			
<b>Zither Diskant Ausklingend</b>	29			
<b>Trompete Mute Solotone</b>	30			
<b>Trompete Mute Harmon</b>	31			
<b>Trompete Mute Cup</b>	32			
	33			
<b>Orgel Gospel Fast</b>	34			
<b>Orgel Full Fast</b>	35			
<b>Orgel Jazz Fast</b>	36			
<b>Orgel Jazz Slow</b>	37			
<b>Orgel Full Slow</b>	38			
<b>Orgel Gospel Slow</b>	39			
	40			
<b>Zupan ADGC Diskant</b>	41			
<b>Zupan GCFBb Diskant</b>	42			
<b>E-Piano 1</b>	43			
<b>E-Piano 2</b>	44			
<b>E-Piano 3</b>	45			
	46			
<b>Kontrabass Ausklingend 2</b>	47		47	47
<b>Kontrabass Normal 2</b>	48		48	48
	49			
<b>Konzertgitarre Diskant 1</b>	50			
<b>Konzertgitarre Diskant 2</b>	51			
<b>Konzertgitarre Akkorde 1</b>	52			
<b>Konzertgitarre Akkorde 2</b>	53			
<b>Konzertgitarre Bass</b>	54			
<b>Mandoline Tremolo 1</b>	55			
<b>Mandoline Verzögert 1</b>	56			
<b>Mandoline</b>	57			
<b>Mandoline Verzögert 2</b>	58			
<b>Mandoline Tremolo 2</b>	59			
<b>Tenorsax Normal</b>	60			
<b>Tenorsax Loop</b>	61			
<b>Tenorsax Unisono</b>	62			
<b>Tenorsax Loop</b>	63			
<b>Altsax Normal</b>	64			
<b>Altsax Loop</b>	65			
<b>Altsax Weich</b>	66			

	<b>Bank 70 (normal)</b>	<b>Bank 71 (Akkorde)</b>	<b>Bank 72 (Eb)</b>	<b>Bank 73 (D)</b>
<b>Altsax Weich Loop</b>	67			
<b>Bariton King Ois isi 1</b>	68			
<b>Bariton King Ois isi 2</b>	69			
<b>Bandoneon</b>	70			
<b>Bandoneon Akkorde</b>	71			
<b>Bandoneon Betont</b>	72			
<b>Bandoneon Bass</b>	73			
<b>Klavier 1</b>	74			
<b>Klavier 2</b>	75			
<b>Klavier 3</b>	76			
	77			
	78			
	79			
<b>Hohner Morino Reg 1 Piccolo</b>	80			
<b>Hohner Morino Reg 2 Clarinet</b>	81			
<b>Hohner Morino Reg 3 Bassoon</b>	82			
<b>Hohner Morino Reg 4 Bandoneon</b>	83			
<b>Hohner Morino Reg 6 Master</b>	84			
<b>Hohner Morino Reg 7 Orchester</b>	85			
<b>Hohner Morino Reg 8 Celesta</b>	86			
<b>Hohner Morino Reg 9 Organ</b>	87			
<b>Hohner Morino Reg 10 Harmonium</b>	88			
<b>Hohner Morino Reg 11 Oboe</b>	89			
<b>Cort Guitar Clean</b>	90			
<b>Cort Guitar Wide Wah</b>	91			
<b>Cort Guitar Chorus</b>	92			
<b>Cort Guitar Chorus 2</b>	93			
<b>Cort Guitar Chorus 3</b>	94			
<b>Cort Guitar Distortion</b>	95			
<b>Cort Guitar Flanger</b>	96			
<b>Cort Guitar Flanger 2</b>	97			
<b>Cort Guitar Tremolo</b>	98			
<b>Bariton B&amp;M Normal Ois isi</b>	99			
<b>Bariton B&amp;M Normal</b>	100			
<b>Bariton B&amp;M Fett</b>	101			
<b>Bariton B&amp;M Kurz</b>	102			
<b>Bariton B&amp;M Diskant</b>	103			
<b>Bariton B&amp;M Diskant Fett</b>	104			
<b>Bariton B&amp;M Diskant Loop</b>	105			
<b>Bariton B&amp;M Fett Ois isi</b>	106			

	<b>Bank 70 (normal)</b>	<b>Bank 71 (Akkorde)</b>	<b>Bank 72 (Eb)</b>	<b>Bank 73 (D)</b>
<b>Bariton B&amp;M Loop Ois isi</b>	107			
<b>Erman Ausklingend</b>	108	108		
<b>Ovation Ausklingend</b>	109	109		
<b>Texan Ausklingend</b>	110	110		
	111			
	112			
	113			
	114			
	115			
	116			
	117			
	118			
	119			
<b>Joggi Bass Normal</b>	120		120	120
<b>Joggi Bass Normal Ois isi</b>	121			
<b>Joggi Bass Normal Diskant</b>	122			
<b>Joggi Bass Hart</b>	123		123	123
<b>Joggi Bass Hart Ois isi</b>	124			
<b>Joggi Bass Hart Diskant</b>	125			
<b>Joggi Bass Ausklingend</b>	126		126	126